
CHANNEL 1
SEND/ FEEDBACK/ RETURN
OUTPUT
MASTER
PHONES
L R L R
CHANNEL MIX
SEND
L R 1 2 3 4
FEEDBACK ROUTING TO CHANNELS
1 2 3 4
PHANTOM +48 V
MIC
LINE
PAD
PREAMP
GAIN
FEEDBACK
3-BAND EQ
INSERT
VOLUME CV
LED
VOLUME CV
VOLUME
CLIP
SIGNAL
PAN CV
LED
PAN CV
PAN
MUTE
SEND 1 CV
LED
SEND 1 CV
SEND 1 LEVEL
SEND 2 CV
LED
SEND 2 CV
SEND 2 LEVEL
SEND 3 CV
LED
SEND 3 CV
SEND 3 LEVEL
SEND 4 CV
LED
SEND 4 CV
SEND 4 LEVEL
CHANNEL MIX
CLIP
SEND 1 OUT
SEND 2 OUT
SEND 3 OUT
SEND 4 OUT
FEEDBACK ROUTING
SEND 1 OUTPUT
SEND 2 OUTPUT
SEND 3 OUTPUT
SEND 4 OUTPUT
RETURN 1 INPUT
RETURN 2 INPUT
RETURN 3 INPUT
RETURN 4 INPUT
RETURN 1 LEVEL
RETURN 2 LEVEL
RETURN 3 LEVEL
RETURN 4 LEVEL
PHONES
PHONES OUTPUT
MASTER VOLUME
MASTER OUTPUT LEFT
MASTER OUTPUT RIGHT
CHANNEL 1
SEND/ FEEDBACK/ RETURN
OUTPUT